

FASTSET

The Fast-Attach® Laptop/Tablet Stand Instructions and Warranty Information



This Kit Includes:

- 1 – Fast-Attach Stand w/Memory Ring System
- 1 – Fast-Clamp
- 1 – Storage Bag
- 2 – Wire Management Clips (w/Tray Lock Feature)
- 1 – Universal Clamp Spacer/Insert



Specifications:

- Adjustable height from 2" – 13" from table surface to back of stand
- Tray support area: 9.5" wide x 8.5" deep.
- Device Capacity: 10lbs or up to 14" laptops & most tablets

Warnings:

- Do not use The Fast-Attach Laptop/Tablet Stand on the sides of Table, your device could fall off the stand.
- Only use the Fast-Attach Accessories with your devices over-hanging the table and not over-hanging the ground.
- Do not use the Fast-Clamp or Fast-Attach Accessories on any table except the Fastset® Utility Table.

For Tips & Tricks on Fastset products watch videos located on the product pages at www.fastsetusa.com

Installing your Fast-Attach® Accessory to the Fastset® Table

STEP 1: Position the Fast-Clamps on to the Fastset Table:

- Determine where you are going to locate your Fast-Attach Accessory and place the clamp on the table edge by squeezing it open & then releasing it into position - be sure the clamp is not located on a fastener on the underside of table (located approximately by small squares on picture below).
- **IMPORTANT:** If you are using your Fast-Attach Stand on the far corners of the Fastset table, you **MUST** install the universal clamp spacer on to the Clamp prior to positioning it on the table.




Spacer Installed



No Spacer



Spacer Installed



STEP 2: Insert the vertical post of your Fast-Attach Accessory:

Before inserting the vertical post, make sure the locking cam lever on the clamp is in the down position. Insert the vertical post through the clamp opening and send the accessory to your preferred height/position then push the cam lever up until it clicks into the locked position.



UN-LOCKED



LOCKED

Using the Features on your Fast-Attach Laptop/Tablet Stand

Collapsing & locking the Laptop/Tablet Tray for transport & storage:


- Simply push the solid stainless-steel quick collapse button located in the middle of the cross bar to collapse the tray. To keep the tray secured to the vertical post when not in use, use the included wire management clip with “tray lock feature” (this has a slot milled into clip for sliding on to tray lip where it meets the vertical post). Remember to slide the clip down to release the tray before deployment.

Changing the Tray Angle with the (repositionable) adjustment release lever:

- With the stand installed and tray locked in the deployed position, loosen the orange lever by turning it counter-clockwise about ½ of a turn or so. Position the tray to the desired angle and re-tighten the orange lever so that the tray cannot move with a medium amount of test force. (It is not necessary to over tighten – remember the max load on the tray is only 10 pounds or less). If the lever ends up in an undesirable position after tightening, pull the lever outwards and re-position the lever so that it’s out of your way and not obstructing the device being used on the tray.
- Once your desired tray angle is set, you will not need to reset it before each use because the quick collapse button will return the tray to the exact same angle every time you set up. When changing devices (such as from a laptop to a tablet), simply repeat the above process to re-adjust the angle.

Using the Memory Ring Feature:

- Simply place the orange O-Ring in one of the 5 preset grooves on the vertical post and use this as a stopping point when setting up your Fast-Attach Accessory. Now you can easily return to the same height without guessing every time you set up.



Fast Set Supports Limited Warranty Details

Fast Set Supports, LLC, herein referred to as "Fast Set Supports", warranty obligations are limited to the terms set forth as follows:

- **Fast Set Supports warrants all Fastset® Tables and Fast-Attach Line of Accessories to be free from manufacturing defects under normal use for a period of Three Years from the date of retail purchase by the original end-user purchaser.**
- **Fast Set Supports warrants all soft products, such as cases, scrims, covers, etc. to be free from manufacturing defects under normal use for a period of One Year from the date of retail purchase by the original end-user purchaser.**
- **If the product is no longer manufactured by Fast Set Supports, and qualifies for repair under the warranty program, the product will be replaced with the closest comparable product as determined by Fast Set Supports.**
- **This warranty does not include damage to the product resulting from normal wear and tear, accident, misuse, improper installation or operation, or unauthorized repair or alterations.**
- **The Limited Warranty does not apply to any non-Fast Set Supports products or sub-brands even if packaged or sold with other products.**
- **Should the product become defective within the warranty provisions, Fast Set Supports will elect to repair or replace the product free of charge at our option, including free return postage, provided it is delivered prepaid to Fast Set Supports.**
- **Fast Set Supports may elect to send original end-user new or refurbished customer-installable replacement product or parts.**
- **Proof of purchase in the form of a dated receipt must be submitted with the returned product.**
- **All products needing to be sent to Fast Set Supports for repair or replacement must have a Return Authorization Number and will be returned to the sender un-repaired if one is not included. Please email your request (with explanation of problem) to Customer Support at support@fastsetusa.com for a Return Authorization Number and return instructions.**
- **It is the sender's responsibility to pay for shipment to Fast Set Supports.**
- **If the product is determined to fall under warranty, Fast Set Supports will pay for return shipping to the customer within the contiguous 48 states.**
- **If a replacement product or part is provided, the original product or part becomes the property of Fast Set Supports.**

Should Fast Set Supports deem a product non-warranty, repair services or replacement parts may be available. Fast Set Supports will contact the sender with repair options.

For answers to any questions regarding warranty and service, please email Customer Support at support@fastsetusa.com

Please register your product at: www.fastsetusa.com

A note from Fastset inventor & founder Trace Van Dyne:

Thank you for your trust in me and the Fastset Brand. We work very hard to create products that are reliable and that provide you an easier, unique way to set-up and perform, because that's what we believe in. When I used to do gigs, I never liked to tighten and loosen knobs, I didn't like things that wobbled or swayed, or that could potentially come apart, and I hated the fact that everything seemed to be made in China. Some products worked fine for a while and others would come apart after just a few uses. There always seemed to be one or two design features missing that would have made them easier to use and more reliable. I would have happily spent a few extra dollars to have it done a little better. So, this is my motivation and inspiration to do things different. You'll find that Fastset doesn't do "knock-offs", we create our own solutions and work diligently to make products that make sense, and, that give our customers the added value of multiple ways to set-up and play.

Thank you again and please don't hesitate to contact us at support@fastsetusa.com if you ever have any questions or need assistance with our products. You can also contact me direct; my personal email is: trace@fastsetusa.com

P.S. If you like what we're doing, please share Fastset with your friends, I appreciate your support!